

ACCESSORIES AND SPARE PARTS FOR CONNECTION HEADS

PIPE-MOUNTING BRACKET - types P1; P2

M8 DIN 934
(Wrench Size=13)
Ø8 DIN 433

M6x8 DIN 912
(Hex Key Size=5)

L=95 (for P2)
L=65 (for P1)

Destination: Transmitter Housing - type: DANAF..., DANDF..., XD-ADF...

Material: zinc-plated carbon steel (ST) or stainless steel (N)

Pipe diameter: ½"÷1" (P1) 1½"÷2" (P2)

Ordering: **Pipe-mounting bracket type P1-ST; P2-ST**

PIPE-MOUNTING BRACKET - type P3

~91

Ø4 DIN 126
Ø4 DIN 127
M4x10 DIN 84

Ø4 DIN 126
Ø4 DIN 127
M8 DIN 934
(Wrench Size=13)

Destination: Junction Box - type: XD-JB85

Material: zinc-plated carbon steel (ST) or stainless steel (N)

Pipe diameter: $D_{max} = \frac{1}{2}'' \div 2''$

Ordering: **Pipe-mounting bracket type P3-ST**

PIPE-MOUNTING BRACKET - type P4

M6 DIN 934
(Wrench Size=10)
Ø6 DIN 127
Ø6 DIN 126

L=80 (for A) L=106 (for B)

Destination: Instrument Housing - type: XD-I80, XD-I80win

Material: zinc-plated carbon steel (ST) or stainless steel (N)

Pipe diameter: $D_{max} = \frac{1}{2}'' \div 1\frac{1}{2}''$ (A), $1\frac{1}{2}'' \div 2''$ (B)
Pipe parallel to sensor

Ordering: **Pipe-mounting bracket type P4-A-ST; P4-A-N; P4-B-ST; P4-B-N**